SYSTEM — PAGE

ANTI-SKID....11
AUTOMATIC TEMPERATURE CONTROL....3
CHARGE, START, RUN....2
DECK LID RELEASE....9
ENGINE COMPARTMENT LAMP....7
EXTERIOR LIGHTING....4
HEATED BACKLITE....10
HORN WITH SPEED CONTROL....11
ILLUMINATION LAMPS....8
IMMERSION HEATER....11
POWER DISTRIBUTION....1
POWER DOOR LOCKS....10
POWER SEATS....9
POWER SUNROOF....5
POWER WINDOWS....9
PROTECTION AND CONVENIENCE....6
RADIO....3
WINDSHIELD WIPER/WASHER....8

WIRING COLOR KEY
PRIMARY COLORS

BLACK	BK
BROWN	BR
TAN	T
RED	R
PINK	PK
ORANGE	O
YELLOW	Y
DARK GREEN	DG
LIGHT GREEN	LG
DARK BLUE	DB
LIGHT BLUE	LB
PURPLE	P
GRAY	GY
WHITE	W
HASH	(H)
DOT	(D)

STRIPE IS UNDERSTOOD AND HAS NO COLOR KEY

BULB CHART

LAMP DESCRIPTION	TRADE NUMBER
A/C & HEATER CONTROLS ILLUM.	161
ALTERNATOR WARNING INDICATOR	194
DOME/MAP SWITCHES	211-2
DOOR OPEN WARNING INDICATOR	194
DUAL BRAKE WARNING INDICATOR	194
ENGINE COMPARTMENT	89
GLOVE BOX	194
HEADLAMP SWITCH ILLUMINATION	1816
HEATED BACKLITE WARNING IND.	194
HI BEAM INDICATOR	194
I/P ASH TRAY ILLUMINATION	161
I/P CIGAR LIGHTER ILLUM.	1891
L.H. BACKUP	1156
L.H. CORNERING	1196
L.H. FRONT DOOR COURTESY	214-2
L.H. FRONT SIDE MARKER	194
L.H. HI BEAM HEAD	4001
L.H. LO BEAM HEAD	4000
L.H. REAR SIDE MARKER	168
L.H. FRONT PARK & T/S	1157NA
L.H. I/P COURTESY	89
L.H. REAR READING	211-2
L.H. STOP PARK & T/S	1157
L.H. TURN INDICATOR	194
LICENSE	168
LOW FUEL WARNING INDICATOR	194
LUGGAGE COMPARTMENT	89
OIL PRESSURE WARNING IND.	194
R.H. BACKUP	1156

LAMP DESCRIPTION	TRADE NUMBER
R.H. CORNERING	1196
R.H. FRONT DOOR COURTESY	214-2
R.H. FRONT SIDE MARKER	194
R.H. HI BEAM HEAD	4001
R.H. LO BEAM HEAD	4000
R.H. REAR SIDE MARKER	168
R.H. FRONT PARK & T/S	1157NA
R.H. I/P COURTESY	89
R.H. REAR READING	211-2
R.H. STOP PARK & T/S	1157
R.H. TURN INDICATOR	194
SEAT BELTS WARNING INDICATOR	194
VANITY MIRROR SWITCH	212-2
W/S/W LOW FLUID WARNING IND.	194
W/S/W/WASHER CONTROLS ILLUM.	1891
WATER TEMP WARNING IND.	194
AM/FM/MPX RADIO	1893
STEREO TAPE/ AM/FM/MPX RADIO	37

COMPONENT — PAGE LOC

61 AMP
ALTERNATOR....2 C12

70 AMP
ALTERNATOR....2 C13

(6)
CLUSTER ILLUMINATION LAMP....8 C11

12 VOLT
BATTERY....2 E3

ACTUATOR
BRAKE SKID CONTROL....11 D13
ILLUMINATED ENTRY....6 B4
THROTTLE....11 F6

ALTERNATOR
REGULATOR....2 E12

AMPLIFIER
CONTROL SPEED....11 E7
LIGHT SENSOR....4 B2
PHOTO UNIT AND....4 E4

BACKLITE
HEATED....10 E4

BATTERY
12 VOLT....1 A3

BUZZER
KEY REMINDER....6 A10

CAPACITOR
RADIO IGNITION INTERFERENCE....2 E6
RADIO IGNITION INTERFERENCE....2 E10

CHOKE
ELECTRIC....2 E13
RADIO RECEIVER SUPPRESSION....3 D4

CLOCK....6 C2

COIL
IGNITION....2 D6

DISTRIBUTOR
8 CYL 400 BREAKERLESS....2 D8

FLASHER
EMERGENCY WARNING....4 A8
TURN SIGNAL....4 A7

GAUGE
FUEL....3 C5

GOVERNOR
W/S WIPER....8 C5

HEATER
ENGINE BLOCK....11 C15
REAR VIEW MIRROR....10 C6

HORN
HIGH PITCH....11 F4
HIGH PITCH....11 F3
LOW PITCH....11 F3
LOW PITCH....11 F5

INDICATOR
FUEL DISTANCE TO EMPTY....7 C14

LAMP
A/C & HEATER CONTROLS ILLUM.....8 C10
ALTERNATOR WARNING INDICATOR....2 B11
DOME/MAP SWITCHES....7 C9
DOOR OPEN WARNING INDICATOR....3 B2
DUAL BRAKE WARNING INDICATOR....3 B3
ENGINE COMPARTMENT....7 D5
GLOVE BOX....6 D9
HEADLAMP SWITCH ILLUMINATION....8 C9
HEATED BACKLITE WARNING IND....10 D5
HI BEAM INDICATOR....4 E11
I/P ASH TRAY ILLUMINATION....8 C11
I/P CIGAR LIGHTER ILLUM....8 A9
L.H. BACKUP....5 E5
L.H. CORNERING....4 E15
L.H. FRONT DOOR COURTESY....6 D11
L.H. FRONT SIDE MARKER....4 D13
L.H. HI BEAM HEAD....4 E8
L.H. LO BEAM HEAD....4 E7
L.H. REAR SIDE MARKER....5 E2
L.H. FRONT PARK & T/S....4 D14
L.H. I/P COURTESY....6 D8
L.H. REAR READING....7 D8
L.H. STOP PARK & T/S....5 E3
L.H. STOP PARK & T/S....5 E4
L.H. TURN INDICATOR....4 D16
LICENSE....5 E5
LOW FUEL WARNING INDICATOR....3 F4
LOW FUEL WARNING INDICATOR....8 C12
LUGGAGE COMPARTMENT....7 C12
OIL PRESSURE WARNING IND....2 B16
R.H. BACKUP....5 E6
R.H. CORNERING....4 E11
R.H. FRONT DOOR COURTESY....6 D12
R.H. FRONT SIDE MARKER....4 D13
R.H. HI BEAM HEAD....4 E9
R.H. LO BEAM HEAD....4 E10
R.H. REAR SIDE MARKER....5 E8
R.H. FRONT PARK & T/S....4 D12
R.H. I/P COURTESY....6 D7
R.H. REAR READING....7 D7
R.H. STOP PARK & T/S....5 E6
R.H. STOP PARK & T/S....5 E7
R.H. TURN INDICATOR....4 D15
SEAT BELTS WARNING INDICATOR....7 E3
VANITY MIRROR SWITCH....7 C12
VANITY MIRROR SWITCH....7 C11
W/S/W LOW FLUID WARNING IND....8 E7
W/S/W/WASHER CONTROLS ILLUM....8 C13
WATER TEMP WARNING IND....2 B15

LIGHT
LOCK CYLINDER ILLUMINATION....6 D6
LOCK CYLINDER ILLUMINATION....6 D

LIGHTER
CIGAR....6 B3
CIGAR....6 E3
CIGAR....6 D3
CIGAR....6 E4

MODULATOR
BREAKERLESS IGNITION....2 C9

MODULE
BRAKE SKID CONTROL....11 A12

MOTOR
2 WAY POWER SEAT....9 D12
BLOWER....3 E10
DOOR LOCK....10 E11
DOOR LOCK....10 E15
L.H. FRONT DOOR POWER WINDOW....9 E3
R.H. FRONT DOOR POWER WINDOW....9 E4
RADIO ANTENNA....3 D13
ROOF SLIDING PANEL....5 F14
SIX WAY POWER BENCH SEAT....9 D9
SIX WAY POWER BENCH SEAT....9 D14
STARTER....2 E2
W/S WASHER PUMP....8 A8
W/S/W 2 SPEED DEPRESSED PARK....8 F3

PANEL
FUSE....1 B1

POTENTIOMETER
AUTOMATIC DIMMER & AUTOLAMP....4 D1

RECEIVER
AM/FM/MPX RADIO....3 A15
STEREO TAPE/ AM/FM/MPX RADIO....8 C15

REGULATOR
INSTRUMENT CLUSTER VOLTAGE....3 E4

RELAY
AUTO TEMP CONTROL SOLENOID....3 D11
BACK WINDOW HEAT CONTROL....10 C3
HEADLAMP DIMMER....4 D6
HORN....11 A6
SEAT BACK LATCH....6 C14
SLIDING PANEL MOTOR CONTROL....5 B16
STARTER MOTOR....1 B4
STARTER MOTOR....2 E3
TRAILER EXTERIOR LAMPS....5 C10
TRAILER EXTERIOR LAMPS....5 C12
TRAILER EXTERIOR LAMPS....5 C13
WARNING INDICATOR....6 D10

RESISTOR
BLOWER MOTOR....3 F10

SENDER
FUEL GAUGE....3 D6
FUEL GAUGE....7 E16

SENSOR
SPEED CABLE....7 F12
SPEED CABLE....11 F8
SURE TRACK....11 D12

SENSOR
CONTINUED...
W/S/W RESERVOIR FLUID LEVEL....8 E7

SOLENOID
A/C CLUTCH....3 E12
CARBURETOR FLOAT BOWL VENT....2 D5
CARBURETOR VALVE CONTROL....3 E13
FRONT SEAT BACK LATCH....6 C16
FRONT SEAT BACK LATCH....6 C15
HEADLAMP COVER VALVE AND....4 F5
LUGGAGE COMPARTMENT....9 E7

SPEAKER
RADIO RECEIVER....3 D14
RADIO RECEIVER....3 D15
RADIO RECEIVER....3 D13
RADIO RECEIVER....3 D16

SWITCH
A.T.C. MODE....3 A11
A.T.C. WATER TEMPERATURE....2 D15
AUTOMATIC HEADLAMP DIMMER....4 D5
BACK WINDOW HEATER CONTROL....10 A3
BACKUP LAMP....4 A13
COURTESY LAMP....6 B11
COURTESY LAMP....6 B12
DECK LID RELEASE....9 B7
DOOR OPEN WARNING LAMP....3 E2
DOOR OPEN WARNING LAMP....3 E1
DUAL BRAKE WARNING....3 E3
FUEL LOW LEVEL WARNING....3 F5
GLOVE BOX LAMP....6 E9
HEADLAMP....1 E9
HEADLAMP....1 E11
HEADLAMP....4 B3
HEADLAMP....4 B5
HEADLAMP....6 B6
HEADLAMP....6 B8
HEADLAMP DIMMER....4 B8
HORN....11 B3
HORN....11 C6
IGNITION....1 A9
IGNITION....2 B3
IGNITION KEY WARNING....6 B9
INTERIOR LAMP....6 D7
INTERIOR LAMP....6 E7
L.H. POWER DOOR LOCK....10 C10
OIL PRESSURE....2 C16
PARK BRAKE SIGNAL LAMP....3 E2
POWER WINDOW....9 D4
POWER WINDOW....9 C12
R.H. POWER DOOR LOCK....10 C14
RADIO ANTENNA....3 A13
SEAT BELT RETRACTOR (L.H.)....7 D4
SEAT BELT WARNING INDICATOR....7 B3
SEAT REGULATOR CONTROL....9 B10
SEAT REGULATOR CONTROL....9 B15
SPEED CONTROL....11 C5
STOPLAMP....4 B9
T/S,EMRGCY, & CORNERING LAMP....4 C10
W/S/W WASHER....8 D1
W/S/W WASHER....8 B5
WINDOW REGULATOR CONTROL....5 D15
WINDOW REGULATOR CONTROL....9 A4

COMPONENT — PAGE LOC

SWITCH
CONTINUED...
A/C CONTROL....3 C9

THERMOSTAT
A/C EVAPORATOR....3 D12

UNIT
PHOTO....4 C1

GROUND CODES

SPLICE CODES

ELECTRICAL SYSTEMS 1979 MARK V
INDEX-SYSTEM AND COMPONENT

EFFECTIVE P.C.R.
SUPERSEDES
DATE 7-12-78

BEPE ELECT INST MAN PAGE E9L-705-INDEX
SERVICE AND TRAINING MAN PAGE INDEX

WIRING COLOR KEY
(PRIMARY COLORS)

BLACK	BK
BROWN	BR
TAN	T
RED	R
PINK	PK
ORANGE	O
YELLOW	Y
DARK GREEN	DG
LIGHT GREEN	LG
DARK BLUE	DB
LIGHT BLUE	LB
PURPLE	P
GRAY	GY
WHITE	W
HASH	(H)
DOT	(D)

STRIPE IS UNDERSTOOD AND HAS NO COLOR KEY

MARK V

365-198M-79