
DECK LID RELEASE SWITCH
6 A IN-LINE CIRCUIT BREAKER
TO POWER WINDOW CIRCUIT BREAKER
IN LINE FUSE C-1114 AUTOMATIC FOOT DIMMER SWITCH
C-1113 AUTOMATIC HEADLAMP DIMMER RELAY
HEADLAMP DIMMER SWITCH
CORNERING LAMP SWITCH
LH DOOR CIGAR LIGHTER ILLUM
CIGAR LIGHTER ILLUM RH DOOR (FRONT)
CIGAR LIGHTER ILLUM RH DOOR (REAR)
LUGGAGE COMPARTMENT SOLENOID
W/S WIPER SWITCH ILLUM
ASH TRAY ILLUM
PHOTO UNIT AND AMPLIFIER
AUTOMATIC DIMMER RHEOSTAT
1 - LO BEAM
2 - AUTOMATIC
3 - OVER-RIDE
HI BEAM INDICATOR
TO A/C CLUTCH SOLENOID
LH PARKING LAMP
LH MARKER LAMP
RH MARKER LAMP
RH PARKING LAMP
RH CORNERING LAMP
LH CORNERING LAMP
LH HEADLAMP OUTBOARD
LH HEADLAMP INBOARD
RH HEADLAMP INBOARD
RH HEADLAMP OUTBOARD
C-1111
BEHIND I/P. FAR L.H. SIDE. AT REAR OF HEADLAMP SWITCH
* AUTOMATIC HEADLAMP DIMMER RHEOSTAT. PART OF HEADLAMP SWITCH
C-1112
IN ENGINE COMPARTMENT. NEAR L.H. HEADLAMP
* HEADLAMP DIMMER PHOTO UNIT AND AMPLIFIER ASSEMBLY
C-1113
L.H. SIDE OF STEERING COLUMN MOUNTING BRACKET
* AUTOMATIC HEADLAMP DIMMER RELAY
C-1114
L.H. TOE BOARD
* FOOT DIMMER SWITCH
C-1115
LOWER L.H. COWL SIDE
C-513
UNDER INSTRUMENT PANEL. R.H. SIDE
C-910
UNDER INSTRUMENT PANEL. L.H. SIDE
C-410
LH TOE BOARD UNDER SHIELD
C-412
BEHIND INSTRUMENT CLUSTER
* PRINTED CIRCUIT BOARD
C-581
BEHIND INSTRUMENT PANEL LH SIDE
C-610
INSIDE LUGGAGE COMPARTMENT BELOW PACKAGE TRAY
C-583
DASH PANEL LEFT OF STEERING COLUMN BEHIND FUSE PANEL
C-583A
DASH PANEL. LEFT OF STEERING COLUMN. ENGINE COMPARTMENT SIDE
C-983
IN R.H. DOOR NEAR FRONT CIGAR LIGHTER OR BEHIND I/P NEAR CIGAR LIGHTER
* CIGAR LIGHTER ILLUMINATION LAMP
C-985
BEHIND W/S WIPER SWITCH
* W/S WIPER SWITCH ILLUMINATION
C-987
ABOVE ASH RECEPTACLE (I/P)
* ASH RECEPTACLE ILLUMINATION
C-911
IN L.H. DOOR ARMREST. AND R.H. DOOR ARMREST-REAR
* CIGAR LIGHTER ILLUMINATION LAMP
C-1006
INSIDE DECK LID. NEAR DECK LID LATCH
* LUGGAGE COMPARTMENT SOLENOID
C-1007
BEHIND GLOVE BOX DOOR
* DECK LID SWITCH
C-1008
UNDER INSTRUMENT PANEL
* CIRCUIT BREAKER (6 AMP)
C-1181
L.H. FRONT FLOOR. NEAR COWL SIDE
* HEADLAMP DIMMER SWITCH
C-1182
ABOVE STEERING COLUMN. R.H. SIDE
* STEERING COLUMN WIRING
C-1183
IN ENGINE COMPARTMENT. BEHIND R.H. FRONT CORNERING LAMP
C-1184
IN ENGINE COMPARTMENT. BEHIND L.H. CORNERING LAMP
C-1185
BEHIND L.H. OUTBOARD HEADLAMP
* L.H. "LO" BEAM HEADLAMP
C-1186
BEHIND L.H. INBOARD HEADLAMP
* L.H. HI BEAM HEADLAMP
C-1187
BEHIND R.H. INBOARD HEADLAMP
* HI BEAM HEADLAMP
C-1188
BEHIND R.H. OUTBOARD HEADLAMP
* R.H. "LO" BEAM
C-1189
IN ENGINE COMPARTMENT. BEHIND R.H. PARKING LAMP
C-1110
IN ENGINE COMPARTMENT. BEHIND L.H. PARKING LAMP
GROUND CODES
G-1101 IN 14290 ON L.H. HEADLAMP MOUNTING BRACKET
G-1102 IN 14290 ON L.H. RADIATOR SUPPORT BRACKET
G-1103 IN 14290 ON R.H. RADIATOR SUPPORT BRACKET
SPLICE CODES
S-503 IN 14485 NEAR TAKEOUT TO DOME MAP LAMP CONNECTOR
S-581 IN 14481. NEAR I/P CIGAR LIGHTER TAKEOUT
S-1101 IN 14290 NEAR TAKEOUT TO AMBIENT TEMP. SWITCH
S-1102 IN 14290 NEAR TAKEOUT TO W/S WASHER PUMP MOTOR
S-1103 IN 14290 NEAR TAKEOUT TO W/S WASHER PUMP MOTOR
1973 MARK IV
PAGE 6 OF 13
LOCATIONS 65 THRU 80
7-1-72